

ELECTRICAL ACCESSORIES

Fluorescent Starters & Wall Plate Inserts

FLUORESCENT STARTERS				
	CATALOG NUMBER	DESCRIPTION	UL	CSA
	FS2	Glow switch starter without reset, 2 pins 14, 15 & 20W.	•	•
	FS4	Glow switch starter without reset, 2 pins 13, 30 & 40W.	•	•
	FS5	Glow switch starter without reset, 2 pins 4, 6 & 8W.	•	•
WALL PLATE INSERTS				
DIMENSIONS	CATALOG NUMBER	DESCRIPTION	FINISH	COLOR
	325I	Mounting strap for blank insert. Box mounted.	Polycarbonate	Ivory
	325W	Changes decorator opening to blank.	Plastic	White
	325			Brown
	325BK			Black
	325LA			Light Almond
	325GRY			Grey
	326I	Mounting strap for blank insert. Box mounted.	Painted	Ivory
	326W	Changes decorator opening to blank.	Steel	White
	326			Brown
	326LA			Light Almond
	327I	Mounting strap for dimmer insert. Box mounted.	Painted	Ivory
	327W	Change from decorator to toggle opening.	Steel	White
	327			Brown
	327LA			Light Almond
	80700I	Mounting strap for blank insert. Box mounted.	Thermoset	Ivory
	80700W	Changes toggle opening to blank.	Plastic	White
	80700LA			Light Almond